CBL Setup Codes

About Cable Codes

Your cable service provider may have "locked" a valid cable code into your remote to keep you from changing the cable code unintentionally.

If you need to program the remote to operate a different device, use the following steps to unlock the remote.

1. Press and hold the **SELECT** key and the **CBL** key until the LED blinks twice.
2. Press **9-9-6**.

   Note: As you press each digit, the mode key should blink.
3. Press **CH▼** to unlock the remote.

Result: You can now set up your CBL key with a different cable code using
t-up mode key.
digits to program the

AUX Setup Codes

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by Scientific-Atlanta could void the user's authority to operate this equipment.

AT8400™ AllTouch® Remote Control Rev B

User's Guide

© 2004 Scientific-Atlanta, Inc. All rights reserved.
AllTouch, Explorer, Scientific-Atlanta and the Scientific-Atlanta logo are registered trademarks and AT8400 is a trademark of Scientific-Atlanta. Inc. Other trademarks mentioned are property of their respective owners. Product and service availability subject to change without notice.

Scientific-Atlanta, Inc., 5030 Sugarloaf Parkway, Box 465447, Lawrenceville, GA 30042
www.scientificatlanta.com

February 2004. Printed in USA 4006382 Rev A

TV Setup Codes

Enter all 4 digits to program the TV mode key.

VCR Setup Codes

Enter all 4 digits to program the VCR mode key.
See **Other VCR Codes** if you want to program your VCR mode key to control another device.

Other VCR Codes

You can program your VCR mode key to control a CD player, DVD, or PVR device. Enter all 4 digits to program the VCR mode key.

Quick Reference

Viewing and Browsing Control

33 GUIDE — Displays the program guide

34 MENU — Displays the Applications Menu

4 INFO — Displays channel and program information

5 + PAGE – — Navigates through settings or the program guide

32 — Moves through selections

7 SELECT — Selects and deselects screen item

31 SETTINGS — Displays the General Settings or Quick settings menus

6 EXIT — Exits settings, menus, and guides

30 A B C — Selects options in menus and the program guide

8 CH — Selects channel, up or down

28 FAV — Views favorite channels

9 LAST — Returns to last channel viewed

22 — Enters channel numbers (also enters your parental control PIN)

21 * — Reserved for future use

15 # — Reserved for future use

PIP Control

20 ON/OFF — Opens or closes the PIP window

19 SWAP — Swaps the contents of the PIP window and the main viewing screen so that the PIP window displays on the main screen

16 MO — Moves the PIP window to another location on the screen

17 + / – — Selects the channels in the PIP window, up or down

18 VIDEO SOURCE — Selects the video source